




Legend

- A** → Loading/unloading Dock Location
- L1** → Service Yard & Loading/unloading Area

Access Route

- -From Vivo City, Sentosa Gateway to RWS Basement 1.
- -Service Road, To Central Zone Basement 2 and USS Level 1.
- -To USS Basement 1 car-park.
- -To USS Level 1.
- -To EXIT from RWS site, back to Vivo City.
- -Re-route back to Basement 1 entrance road and EXIT to Sentosa



EQUARIUS HOTEL LOADING BAY

EH Loading Bay V

Equarius Hotel

Turn Left Point from Loading Dock M

